FORMULARY INC.

PO Box 950 • Condon MT 59826 • 406-754-2891 • FAX 406-754-2896 E-MAIL formulary@montana.com

FORMULARY TD-16R REPLENISHER

MAKES ONE LITER CONCENTRATE

TD-16R functions identically to D-76R, except that it is much more consistent in use. D-76R, if mixed too vigorously and stored, shows a significant rise in contrast. This is eliminated in TD-16. or TD-16R. Otherwise image quality, grain, speed, MTF, etc. are identical.

CHEMICAL SAFETY

All chemicals are dangerous and must be treated with respect. Please read the chemical warnings on each package.

Some individuals become sensitized (develop allergic symptoms or rashes) when using certain chemicals- IF FOR ANY REASON YOU DO NOT WANT TO ASSUME ALL RISKS, PLEASE RETURN THE CHEMICALS FOR A FULL REFUND.

Consult with local sewer and water authorities regarding proper disposal of darkroom chemicals in your area.

HOW TO MIX TD-16R

Mixing is very. simple. place 750 ml of water at about 120°F in a container. Slowly add the contents of packet A to the water while stirring gently. Continue stirring for one minute until the solution is clear; slowly add the contents of packet B, and stir one minute. If the developer has not completely dissolved let it set for fifteen minutes, then stir one minute more. DO NOT SHAKE THE DEVELOPER OR STIR TOO VIGOROUSLY. Add enough water to equal one liter in all. Place the stock in bottles filled to the top, and seal tightly.

Note: better results may be obtained if the water used for making the stock and working solutions is, boiled for three minutes and cooled to 120°F before mixing. Use: distilled water if you have any doubts about the quality of your water supply - especially if you live in an area with hard water. In most areas of the country ordinary tap water can be used. without problems, but distilled or demineralized water is always preferable.

DIRECTION FOR USE:

Only use TD-16R concentrate with undiluted TD-16. Add 30 ml of TD-16R for each 36 exposure - 35mm roll processed in TD-16, discarding a small amount of used TD-16 solution, if necessary, to maintain the original solution volume. Discard the entire replenished solution after 25 rolls per liter have been developed.



FORMULARY INC.

P.O. Box 950 • Condon MT 59826 • 406-754-2891 • FAX 406-754-2896 E-mail: Formulary@montana.com